



### Exploded View

Points "A" screw together

O-Ring B slides over valve seat 3

Shaft at "C" passes through valve body and link actuator to "C"

### Parts List

1- Nozzle Shroud	10- Valve Stem Bushing
2- Nozzle*	11- Valve Body
3- Valve Seat	12- Trigger
4- "O"-Ring	13- Link Actuator
5- Valve Stem	14- Stainless Steel Washer
6- Valve Guide	15- "E" Ring
7- Stainless Steel Spring	16- "E" Ring
8- Spring Guide	17- Housing
9- "O"-Ring	18- Inlet Pipe

Water Boss - long trigger (300-1/2-L)

Water Boss - short trigger (300-1/2-S)

Repair Kit "RK-300-A" contains parts 1 - 4

Repair Kit "RK-300-B" contains parts 1 - 11

\*300 series has two nozzle sizes. The standard nozzle has a smooth face.

The additional nozzle tip is designed to reduce water consumption in gallons used per minute.

\*\*Note: When using the Water Boss in conjunction with the DynaFluid steam and

**WATERBOSS**   
Model # 300-1/2-L, or -S

Lilly Engineering Company, Inc.  
P.O. Box 173, 217 Catalpa Street  
Itasca, Illinois 60143-0173  
630-773-2222 Fax: 630-773-3443  
[www.lillyengineering.com](http://www.lillyengineering.com)